



2007.5-2025 6.7L Cummins

PCV CCV Reroute/Delete Kit

Installation Manual





Warning Regarding Emissions Laws

Not legal for sale or use on pollution-controlled motor vehicles anywhere in the United States. Legal ONLY for off-road competition racing vehicles and cannot be used on vehicles that are operated on public streets, roads, or highways.



Disclaimer

(1) Assumption of Responsibility

By installing this product on your vehicle, you assume all risks and legal liabilities associated with the use of this product.

(2) Regulatory Compliance Obligations

- You are responsible for ensuring that your vehicle fully complies with federal, state and local emission regulations. (Federal and certain local laws prohibit the removal, modification or disabling of any component that affects vehicle emissions or safety design.)
- Fine penalties or fines resulting from the removal of vehicle emission equipment shall be borne by the end user.
- Use on public roads or highways is prohibited. Violators may face fines.
- All civil penalties or fines resulting from the removal of vehicle emission equipment shall be borne by the end user.

(3) Impact of Factory Warranty

Due to the high performance characteristics of this product, the factory warranty provided by the vehicle manufacturer may be affected and invalidated.

(4) Product Misuse Disclaimer

The seller assumes no liability for improper use or installation of the product. By installing this product, you are deemed to have released the seller from any and all legal liability related to its use.

(5) Regional Legal Restrictions

The installation or use of this product may be restricted according to local regulations. Please check all applicable laws before operation.

(6) Legal Liability Exemption

The purchaser and end user agree to release the seller from any claims, damages, lawsuits, injuries or expenses caused by the following actions, including but not limited to:

- Breaking the terms of this statement, product disclaimer or installation instructions;
- Direct, indirect, incidental, punitive, statutory or special damages or penalties arising from the installation or use of this product.



Installation Precautions

(1) Never Work on a Hot Vehicle

If the vehicle is in use, severe burns may occur. Allow the vehicle to cool before installation. Always wear goggles when working on or under any vehicle.

(2) Remove Rust/Lubricate Fully Before Disassembly

Older vehicles have more rust on the bolts. Before disassembly, spray rust remover (WD-40) and wait for 10 minutes. Remove rust/lubricate fully before disassembly to prevent damage to the screws. (We have received many cases of damage, so we would like to remind you of this.)

STEP 1

Remove the CCV outlet tube.



Image 1



Note: The turbocharger compressor vanes can be damaged by even the smallest particles. When removing any turbocharger or engine air intake system component, ensure that no debris enters the system. Failure to do so may result in damage to the turbocharger.

STEP 2

Remove the Turbo inlet tube.




Image 2



Note: After removing the original pipe, the interface needs to be covered to prevent foreign matter from entering and avoiding damage to the engine and turbine.

STEP 3

Install provided filter and cap onto the port on the stock intake where you removed the factory breather hose earlier on in the process." No need to clamp or zip tie as this has no pressure behind it".



Image 3